



SIMPLY OAK

OSMO Hard Wax Oil Application

SURFACE PREPARATION

1ST STEP

Sandpaper grit: very coarse to middle (P 40-80). Depending on the surface, start with either P 40 (for old finishes) or P 80 (for raw wood) sanding grit.

Important: please do not skip steps in grit whilst sanding.

Tools: sandpaper or belt sander.

2ND STEP

Grit: middle (P 100). Tools: sandpaper or belt sander or a single or multiple disc machine.

3RD STEP

Fill cracks and holes: with Osmo wood filler (for up to 2 mm in depth).

4TH STEP

Grit: middle (P 100). Tools: sandpaper or sanding mesh or a single or multiple disc machine.

5TH STEP

Grit: fine (P 120). Tools: sandpaper or sanding mesh or a single or multiple disc machine.

WOOD FINISH APPLICATION

Finished surface in 2 days, 2 coats

1. First coat on the raw, sanded wood approx. 35 ml/m².
2. Mistakes in the wet coating can be corrected up to 30 minutes after the first application.

3. Drying time approx. 8-10 hours (normal climatic conditions, 72°F /50 % rel. humidity). Lower temperatures and/or higher humidity can increase drying time. Allow for good ventilation.
4. If desired, the dried finish can be smoothed with fine grain sandpaper (P400) or with a Scotchpad before applying the second coat.
5. Second coat approx. 35 ml/m².
6. Drying time approx. 8-10 hours; see point 3.

Simply Beautiful. Simply Natural. Simply Oak.