



MAINTENANCE AND CLEANING INSTRUCTIONS

Maintenance and cleaning guidelines for the following floors:

- All solid and engineered floors

Warning

- The first 30 days after installation avoid any moisture or water on the floor.
- Remove dirt only with a vacuum cleaner or use other dry cleaning methods.

Cleaning

- Mop stubborn dirt away with Floorservice Parquet Cleaner.
- Mix approximately 100 ml Parquet Cleaner with 10 litres of clean water and clean the floor with a well squeezed mop
- Allow the floor to dry completely before walking on it.
- Floorservice Parquet Cleaner can be used for regular cleaning.

Maintenance

- Depending on the intensity of use, treatment with Floorservice Maintenance oil will keep the floor in optimum condition.
- Use natural maintenance oil for dark and natural oiled floors.
- For white oiled floors the natural- and white maintenance oil can both be used. With the white maintenance oil the floor will look whiter. With the natural maintenance oil the floor will look more natural. Also, it's possible to mix the two maintenance oils.
- First clean the floor with Floorservice Parquet cleaner as described above and allow it to dry completely.
- Apply Floorservice maintenance oil in small areas in an even layer with a cloth with the grain of the wood
- For larger areas, we recommend to use a buffing machine.
- Disperse the maintenance oil in the shape of a snake and polish it in with a buffing machine using a thick white pad.
- 1 litre maintenance oil is sufficient for approximately 80 to 100 m².
- Depending on ambient temperature and ventilation the drying time is 6 to 12 hours.
- For detailed information refer to the technical product sheets and the information on the packaging.
- Floorservice Maintenance oil can be used for 1 to 4 times per year depending on the intensity of use.



Frequency

- Daily cleaning : Floorservice Dry Clean Set
- Regular cleaning : Floorservice Parquet Cleaner
- Maintenance normal use : Floorservice maintenance oil 1 to 2 times a year
- Maintenance intensive use : Floorservice maintenance oil 3 to 4 times a year